

**Kaupelis, et al. v. Harbor Freight Tools USA, Inc.**

In the United States District Court for the Central District of California

Case No. 8:19-cv-01203-JVS-DFM

**Instructions for Destruction of Unreturned Class Product**

If you currently own a Harbor Freight Tools Portland, One Stop Gardens, and Chicago Electric brands' 14 Inch Electric Chainsaw (SKU# 67255 and 61592) ("CHAINSAW"), the best way to receive a replacement or refund and properly dispose of the CHAINSAW is to return it to your local Harbor Freight retail store. If you are unable to return the CHAINSAW to a local Harbor Freight retail store, you can submit a Claim for a gift card or check refund and ensure proper destruction of the CHAINSAW so it is no longer usable, as described below.

**How to properly destroy the CHAINSAW:**

- While the CHAINSAW is unplugged and in the off-position, cut the power cord, completely detaching it from the CHAINSAW.

If the CHAINSAW has been properly destroyed, it will be unusable and incapable of becoming usable. Take a photo of the CHAINSAW, the method of destruction, and the CHAINSAW's SKU or label. Submit the photo(s) to the Settlement Administrator along with your Claim Form.

Dispose of the chainsaw consistent with all local, state, and federal disposal requirements and restrictions.